



FLATWARE GASTROLINE HOTEL AND RESTAURANT EQUIPMENT HOLLOWWARE



HOTEL AND RESTAURANT EQUIPMENT GASTROLINE HOLLOWWARE

ROLINE

FLATWARE

ARIANE
BAGUETTE
CROISÉ
FILET
FLEURIER
HEXAGONA
OCEANA
RHÔNE
SAVOIA
VALDI

FLATWARE

FLATWARE

ARIANE



RHÔNE



VALDI



FILET



FLATWARE

FLEURIER



HEXAGONA



OCEANA



CROISÉ



FLATWARE

SAVOIA



BAGUETTE



OUR COLLECTION HAS BEEN DESIGNED WITH THE GREATEST CARE AND RESPECTS THE HIGHEST CRITERIONS OF QUALITY WHICH HAVE MADE THE REPUTATION OF BEARD SINCE 120 YEARS

Table Spoon



Table Fork



Table Knife



Steak Knife



Dessert Spoon



Dessert Fork



Dessert Knife



Fish Fork



Fish Knife



Tea / Coffee Spoon



Mocca Spoon



Soup Ladle



Sauce Ladle




Serving Spoon



Serving Fork



Punch Ladle



Carving Fork



Carving Knife



Cake Server



Bouillon Spoon



Butter Knife



Sugar Tong



Salad Serving Tong



Cake Fork



Snail Fork




Cheese Knife



SILVERPLATED FLATWARE

DEPOSIT OF THE SILVER COATING:

AS INDICATED IN THE ILLUSTRATION BELOW:



THE PARTS MOST SUBJECT TO WEAR ARE PARTICULARLY REINFORCED

STRONG SILVERPLATING PROCESS — DISHWASHER PROOF

STAINLESS STEEL FLATWARE

POLISHING: MIRROR OR SATIN FINISH, ACCORDING TO PATTERN

SPECIAL SURFACE FINISHING UPON REQUEST

BASIC METAL: HIGH QUALITY RUST & ACID RESISTANT 18/10 STAINLESS STEEL



BREAKFAST

SERVICE

BANQUET

BAR

ROOM SERVICE

HOLLOWWARE

HOLLOWWARE

BREAKFAST EQUIPMENT

COFFEE POT



		S/S	Slv
30 CI	3021 0104 00	01	
50 CI	3022 0105 00	01	
75 CI	3023 0106 00	01	
100 CI	3024 0107 00	01	
150 CI	3025 0300 00	01	

TEA POT



		S/S	Slv
30 CI	3016 0109 00	01	
50 CI	3017 0110 00	01	
75 CI	3018 0111 00	01	
100 CI	3019 0108 00	01	
150 CI	3020 0300 00	01	

INSULATED POT



		--	Slv
40 CI	3038 0116 03	01	
60 CI	3039 0117 03	01	
100 CI	3040 0118 03	01	

MILK POT



		S/S	Slv
15 CI	3031 0112 00	01	
20 CI	3022 0113 00	01	
30 CI	3023 0114 00	01	
50 CI	3024 0115 00	01	

**TEA/COFFEE POT
WITH SPOUT**



		S/S	
100 CI	3029 0107 00		
150 CI	3030 0300 00		

WATER PITCHER (A)



		S/S	Slv
100 CI	4028 0107 00	01	
150 CI	4029 0108 00	01	

SUGAR BOWL W/COVER



		S/S	Slv
30 CI	3015 0115 00	01	
40 CI	3016 0116 00	01	

WATER PITCHER W/ICE



		S/S	Slv
150 CI	4033 0107 00	01	

BUTTER DISH



10cm 3047 0051 00 | 01 S/S Slv

BUTTER CLOCHE



8 cm 3048 0052 00 | 01 S/S Slv

EGG CUP



4cm 3051 0108 00 | 01 S/S Slv

BREAD BASKET



20 cm 3056 0096 00 | 01 S/S Slv
25 cm 3057 0096 00 | 01
30 cm 3058 0096 00 | 01

TOAST HOLDER



6 slices 3057 0220 00 | 01 S/S Slv

RECTANGULAR TRAY



41 x 61 cm 3058 0701 00 | 01 S/S Slv
48 x 68 cm 3059 0702 00 | 01

JAM TREE



3 pots 3055 0053 00 | 01 S/S Slv
5 pots 3056 0054 00 | 01

TEA STRAINER



L.: 16 cm 3034 0305 00 | 01 S/S Slv

HOLLOWWARE

SERVING EQUIPMENT

ROUND TRAY



		S/S	Slv
25 cm	2059 0001 00	01	
30 cm	2060 0002 00	01	
35 cm	2061 0003 00	01	
40 cm	2062 0004 00	01	
50 cm	2063 0005 00	01	
60 cm	2064 0006 00	01	

SERVING TRAY (RECTANGULAR)



		S/S	Slv
44 x 34 cm	2069 0034 00	01	
51 x 20 cm	2070 0035 00	01	
51 x 27 cm	2071 0036 00	01	
51 x 44 cm	2072 0037 00	01	
53 x 35 cm	2073 0038 00	01	
56 x 33 cm	2073 0050 00	01	
61 x 41 cm	2074 0039 00	01	
68 x 48 cm	2075 0040 00	01	
70 x 18 cm	2999 0099 00	01	

ROUND TRAY W/RIM



		S/S	Slv
25 cm	5500 0001 00	01	
30 cm	5501 0002 00	01	
35 cm	5502 0003 00	01	
40 cm	5503 0004 00	01	
50 cm	5504 0005 00	01	
60 cm	5505 0006 00	01	

RECTANGULAR TRAY W/HANDLES



		S/S	Slv
44 x 34 cm	5526 0034 00	01	
51 x 20 cm	5527 0035 00	01	
51 x 44 cm	5528 0037 00	01	
53 x 35 cm	5529 0038 00	01	
56 x 33 cm	5529 0050 00	01	
61 x 41 cm	5530 0039 00	01	
68 x 48 cm	5531 0040 00	01	

ROUND PLATTER



		S/S	Slv
27 cm	2037 0009 00	01	
29 cm	2038 0010 00	01	
32 cm	2039 0011 00	01	
35 cm	2040 0012 00	01	
40 cm	2041 0013 00	01	
50 cm	2042 0014 00	01	

RECTANGULAR PLATTER



		S/S	Slv
33.5 x 32.5 cm	2051 0020 00	01	
53 x 35 cm	2052 0021 00	01	
60 x 40 cm	2053 0022 00	01	

OVAL PLATTER



		S/S	Slv
28 x 19 cm	2027 0014 00	01	
33 x 22 cm	2028 0015 00	01	
37 x 25 cm	2029 0016 00	01	
42 x 29 cm	2030 0017 00	01	
48 x 32 cm	2031 0018 00	01	
55 x 35 cm	2032 0019 00	01	
65 x 40 cm	2033 0020 00	01	
75 x 47 cm	2034 0021 00	01	

SQUARE PLATTER



		S/S	Slv
33 x 33 cm	2090 0001 00	01	

HOLLOWWARE

SERVING EQUIPMENT

VEGETABLE DISH W/COVER




				S/S	Slv
13 cm	30 Cl	2080 0151 00	01		
15 cm	50 Cl	2080 0152 00	01		
17 cm	70 Cl	2080 0157 00	01		
20 cm	120 Cl	2081 0158 00	01		
22 cm	170 Cl	2082 0159 00	01		
26 cm	300 Cl	2083 0160 00	01		

SOUP TUREEN W/COVER



				S/S	Slv
17 cm	200 Cl	2075 0022 00	01		
22 cm	300 Cl	2076 0023 00	01		
26 cm	500 Cl	2077 0024 00	01		

DISPLAY STAND (3 LEVELS)



				S/S	Slv
Height: 28 cm		5530 0019 00	01		

PETIT-FOUR STAND (2 LEVELS)



				S/S	Slv
2 Levels	h.: 25 cm	5029 0089 00	01		
3 Levels	h.: 37 cm	5030 0090 00	01		

DOME CLOCHE



		S/S	Slv
14 cm	2077 0077 00	01	
17 cm	2016 0022 00	01	
22 cm	2017 0023 00	01	
26 cm	2018 0024 00	01	
28 cm	2019 0270 00	01	
31 cm	2020 0271 00	01	

DOME CLOCHE DÉCOR



		S/S	Slv
17 cm	2022 0022 00	01	
22 cm	2023 0023 00	01	
26 cm	2024 0024 00	01	
28 cm	2014 0270 00	01	
31 cm	2015 0271 00	01	

PLATE COVER - STACKABLE



		S/S	Slv
25 cm	2046 0060 00	01	
27 cm	2047 0061 00	01	
28 cm	2048 0062 00	01	
31 cm	2049 0063 00	01	

FINGER BOWL W/UNDERLINER



		S/S	Slv
12 cm	4021 0037 00	01	

HOLLOWWARE

SERVING EQUIPMENT

SOUS-PLAT



		S/S	Slv
φ 30 cm	2001 0072 00	01	
φ 33 cm	2002 0073 00	01	
φ 35 cm	2003 0074 00	01	

OVAL TRAY



		S/S	Slv
21 x 14 cm	2500 0001 00	01	
27 x 21 cm	2504 0002 00	01	
30 x 23 cm	2505 0003 00	01	
35 x 26 cm	2506 0004 00	01	

CASH TRAY (RECTANGULAR)



		S/S	Slv
21 x 14 cm	2098 0002 00	01	

SOUS-PLAT W/RIM



		S/S	Slv
φ 30 cm	2501 0076 00	01	
φ 33 cm	2502 0077 00	01	
φ 35 cm	2503 0078 00	01	

CAKE PLATTER



		S/S	Slv
φ 25 cm	5211 0001 00	01	
φ 30 cm	5212 0002 00	01	
φ 35 cm	5213 0003 00	01	
φ 40 cm	5214 0004 00	01	

**MULTIPURPOSE BOWL
(FINGER BOWL)**



		S/S	Slv
φ 12 cm	4421 0037 00	01	

CAVIAR RING & INSERT



			S/S	Slv
Insert	8 cm	2087 0043 00	01	
Ring	16 cm	2088 0044 00	01	

CAVIAR DISH



			S/S	Slv
16 cm	2086 0042 00	01		

OYSTER TRAY ON STAND



			S/S	Slv
26 cm	2091 0090 00	01		

BOTTLE COASTER



			S/S	Slv
14 cm	4030 0080 00	01		

ESCARGOT DISH



			S/S	Slv
14 cm - 6 pcs	2084 0028 00	01		
18 cm - 12pcs	2085 0029 00	01		

SALMON BOARD



			S/S	Slv
90 x 20 cm	7710 0059 00	01		

HOLLOWWARE

SERVING EQUIPMENT

FRUIT BOWL (ROUND)



			S/S	Slv
φ	22 cm	2095 0030 00	01	
φ	26 cm	2096 0031 00	01	

FRUIT SALAD PUNCH BOWL



			S/S	Slv
3 GAL		2411 0224 00	01	

BREAD/FRUIT BOWL (OVAL)



			S/S	Slv
25 x 15 cm		8801 0001 00	01	
30 x 17 cm		8802 0002 00	01	
40 x 22 cm		8803 0003 00	01	

BREAD/FRUIT BASKET



			S/S	Slv
φ	25 cm	8701 0001 00	01	
φ	30 cm	8702 0002 00	01	

CHEESE DISH



			S/S	Slv
φ	10 cm	2089 0048 00	01	

OIL & VINEGAR SET



17 x 8 cm S/S Slv
2069 0069 00 | 01

SALT & PEPPER SHAKER



h.: 6 cm S/S Slv
2097 0047 00 | 01

OVAL PLATE W/COVER



55 x 30 cm S/S Slv
2530 0017 00 | 01

COOLING DISPLAY TRAY



φ 40 cm S/S Slv
5077 7081 00 | 01

SAUCE BOAT



20 Cl S/S Slv
2006 0028 00 | 01
40 Cl 2007 0029 00 | 01

PUNCH BOWL



5 GAL S/S Slv
4012 0025 00 | 01

BREAD STIKS HOLDER



h.: 12 cm S/S Slv
2844 2222 00 | 01
h.: 14 cm 2845 2223 00 | 01
h.: 18 cm 2846 2224 00 | 01

HOLLOWWARE

BANQUET EQUIPMENT

**RECTANGULAR ROLL-TOP CHAFING DISH
S/S TUBE LEGS**



62 x 46 x 42 cm S/S Slv
5032 0126 00 | 01

RECTANGULAR BUILT-IN UNIT



62 x 46 cm S/S Slv
5880 0001 00 | 01

**ROUND ROLL-TOP CHAFING DISH
S/S TUBE LEGS**



S/S Slv
 Ø 25 cm 5033 0010 00 | 01
 Ø 30 cm 5034 0011 00 | 01
 Ø 35 cm 5035 0012 00 | 01

INSERT FOR RECTANGULAR CHAFING DISH



53 x 32.5 x 6.5 cm S/S
5055 0121 00

S/S ROUND CHAFING DISH ROLL-TOP



		S/S	Slv
25 cm	5133 0010 00	01	
30 cm	5134 0011 00	01	
35 cm	5135 0012 00	01	

RECTANGULAR ROLL-TOP CHAFING DISH



		S/S	Slv
62 x 46 x 42 cm	5572 0126 00	01	

INSERT 1/2 FOR RECTANGULAR CHAFING DISH



		S/S
35.5 x 32.5 x 6.5 cm	5077 0124 00	

S/S RECTANGULAR CHAFING DISH ROLL-TOP



		S/S	Slv
62 x 46 x 42 cm	5132 0126 00	01	

HOLLOWWARE

BANQUET EQUIPMENT

ROUND BUILT-IN UNIT



		S/S	Slv
25 cm	5881 0002 00	01	
30 cm	5882 0003 00	01	
35 cm	5883 0004 00	01	

ROUND ROLL-TOP CHAFING DISH



		S/S	Slv
25 cm	5573 0010 00	01	
30 cm	5574 0011 00	01	
35 cm	5575 0012 00	01	

INSERT 1/2 FOR ROUND CHAFING DISH



	S/S
35 cm	5177 0192 00

INSERT FOR ROUND CHAFING DISH



	S/S
20 cm	5058 0255 00
25 cm	5059 0256 00
30 cm	5060 0257 00
35 cm	5061 0192 00

DÉCOR ROUND CHAFING DISH



35 cm S/S 5043 0127 00

SAUCE CHAFING DISH



		S/S	Slv
15 cm	5048 0249 00	01	
20 cm	5049 0250 00	01	

SOUP INSERT



20 cm - 4 Ltr. S/S 5054 0135 00

SOUP CHAFING DISH



30 cm - 4 Ltr. S/S 5072 0136 00

HOLLOWWARE

BANQUET EQUIPMENT

WEDDING CAKE STAND



		S/S	Slv
3 Levels	5072 0139 00	01	
5 Levels	5073 0140 00	01	

CARVING STATION "ELECTRIC"



		S/S
100 x 50 cm - 3 lamps	9000 0001 00	

**ROUND DISPLAY TRAY FLEURY
(WITH OR WITHOUT HANDLES)**



		S/S	Slv
30 cm	5560 0002 00		01
35 cm	5561 0003 00		01
40 cm	5562 0004 00		01
50 cm	5563 0005 00		01
60 cm	5564 0006 00		01

**OVAL DISPLAY TRAY FLEURY
(WITH OR WITHOUT HANDLES)**



		S/S	Slv
27 x 21 cm	5504 0701 00		01
30 x 23 cm	5505 0702 00		01
35 x 26 cm	5506 0703 00		01

**RECTANGULAR DISPLAY TRAY FLEURY
(WITH OR WITHOUT HANDLES)**



		S/S	Slv
34 x 26 cm	5568 0033 00		01
44 x 18 cm	5569 0112 00		01
44 x 34 cm	5569 0034 00		01
51 x 44 cm	5573 0042 00		01
53 x 35 cm	5573 0038 00		01
56 x 33 cm	5569 0037 00		01
61 x 41 cm	5574 0039 00		01
68 x 48 cm	5575 0040 00		01

**SQUARE DISPLAY TRAY FLEURY
(WITH OR WITHOUT HANDLES)**



		S/S	Slv
25 x 25 cm	5578 8000 00		01
28 x 28 cm	5579 8000 00		01
31 x 31 cm	5580 8001 00		01
35 x 35 cm	5581 8002 00		01
41 x 41 cm	5582 8003 00		01

HOLLOWWARE

BANQUET EQUIPMENT

FRUIT STAND




S/S Slv
h.: 50 cm - ϕ 30 cm, ϕ 38 cm 2 Levels 3029 0018 00 01
h.: 65 cm - ϕ 30 cm, ϕ 38 cm, ϕ 48 cm 3 Levels 3030 0019 00 01

TRAY/PLATE STAND




S/S
Rectangular tray: 28 x 38 cm 8722 0003 00
Round tray: ϕ 30cm

ORANGE STAND



S/S
 ϕ 30cm h.: 60 cm 8755 5555 00

TRIO BUFFET DISPLAY



S/S
h.: 30 cm 8763 0003 00

DUAL BUFFET DISPLAY



S/S
h.: 40 cm 8765 0006 00

PYRAMID DISPLAY STAND




S/S
h.: 55 cm 8767 0008 00

**PLATE DISPLAY
3 LEVELS**



S/S
h.: 30 cm 8764 0004 00

PLATE CARRIER



S/S
h.: 45 cm 8764 0005 00

TRAY STAND



S/S
25 x 25 x 20 cm 8768 0009 00

TRAY/PLATE STAND



S/S
20 x 20 x 25 cm 8766 0007 00

**BUFFET DISPLAY STAND
SQUARE**



	S/S	Slv
18 x 18 cm	8761 0001 00	01
23 x 23 cm	8761 0002 00	01
26 x 26 cm	8761 0003 00	01

**BUFFET DISPLAY STAND
ROUND**



	S/S	Slv
25 cm	8762 0002 00	01
30 cm	8762 0003 00	01
35 cm	8762 0004 00	01

HOLLOWWARE

BANQUET EQUIPMENT

CANDEL STAND
(5 LIGHTS)



5 Lights S/S Slv
5666 0555 00 | 01

CANDELABRA
(3 LIGHTS)



h: 42cm S/S Slv
5082 0097 03 | 01

CANDEL STAND
W/GLASS




h: 22cm S/S Slv
5079 0098 00 | 01

FLOWER VASE



	S/S	Slv
Flute-h.: 18 cm	2072 0040 00	01
Flower-h.: 16 cm	2471 0041 00	01

TABLE NUMBER STAND



	S/S	Slv
h: 30 cm	5074 0100 00	01

TABLE NUMBERS



	S/S	Slv
7 x 5 cm	5075 0099 00	01

NAPKIN RING




	S/S	Slv
φ 5 cm	2877 0001 00	01

HOLLOWWARE


BAR EQUIPMENT

WINE COOLER STAND



S/S Slv
h: 60 cm 4004 0066 00 | 01

BOTTLE HOLDER



S/S Slv
L: 28 cm 4818 0079 00 | 01

WINE BOTTLE HOLDER



S/S Slv
L: 40 cm 8818 0079 00 | 01

ICE TONG



S/S Slv
L: 18 cm 4017 0071 00 | 01

WINE COOLER W/KNOBS



S/S Slv
φ 19 cm h: 20 cm 4002 0064 00 | 01

ICE BUCKET W/KNOBS



S/S Slv
φ 15 cm h.: 11.5 cm 4011 0064 00 | 01
φ 16 cm h.: 13.5 cm 4012 0065 00 | 01

INSULATED ICE BUCKET
(LIFT-TOP)



100 Cl S/S Slv
4011 0071 00 | 01

CHAMPAGNÈRE FOOTED



22 cm h: 22 cm S/S Slv
4006 0211 00 | 01

SORBETIÈRE



100 Cl h: 23 cm S/S Slv
4809 0070 00 | 01

WINE BUCKET TABLE HOLDER



L: 60 cm S/S Slv
4804 0066 00 | 01

HOLLOWWARE

BAR EQUIPMENT

COCKTAIL SHAKER



S/S Slv
h: 22 cm 4019 0075 00 | 01

COCKTAIL STRAINER



S/S Slv
L: 20 cm 4020 0076 00 | 01

ICE CREAM CUP



		S/S	Slv
h.: 6 cm	9 cm	3042 0038 00	01
h.: 10 cm	10 cm	3043 0039 00	01

LIQUOR MEASURE SET



		S/S	Slv
2.5 Cl	4819 8075 00	01	
3.75 Cl	4819 8076 00	01	
4.1 Cl	4819 8077 00	01	

COCKTAIL SPOON



S/S Slv
L: 23 cm 4022 0077 00 | 01

MEZZEH STAND
3 COMPTS



S/S Slv
3 x 8 cm 4826 0037 00 | 01

PUNCH BOWL



5 GAL 4012 0025 00 S/S Siv
01

BAR DISPLAY BOWL



5 GAL 4800 0025 00 S/S Siv
01

MULTI-PURPOSE DISH



23 cm 5500 0001 00 S/S Siv
30 cm 5501 0002 00 01
35 cm 5502 0003 00 01

PUNCH BOWL - DÉCOR



3 GAL 4015 0027 00 S/S Siv
01

HOLLOWWARE


ROOM SERVICE EQUIPMENT

RECTANGULAR ROOM SERVICE TRAY



		S/S	Slv
61 x 41 cm	5030 0038 00	01	
68 x 48 cm	5031 0039 00	01	

FLAT-TOP PLATE COVER



		S/S	Slv
27 cm	2047 0061 00	01	
28 cm	2048 0062 00	01	
31 cm	2049 0063 00	01	

SAUCE CHAFING DISH



		S/S	Slv
20 cm	5049 0250 00	01	
25 cm	5050 0251 00	01	

LOUNGE CHAFING DISH ROLL-TOP



		S/S	Slv
25 cm	5555 0251 00	01	

BUTTER CLOCHE



	S/S	Slv
8 cm cm 2076 0076 00	01	
9 cm cm 2077 0077 00	01	

VIP FRUIT BASKET



	S/S	Slv
25 cm 8701 0001 00	01	
30 cm 8702 0002 00	01	

INSULATED ICE BUCKET



	S/S	Slv
100 CI 4010 0070 00	01	

INSULATED POT



	S/S	Slv
40 CI 3038 0116 00	01	
60 CI 3039 0117 00	01	
100 CI 3040 0118 00	01	

